


- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- NOTE: For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.


**For 83" SD  
Models SL11, SL14,  
SL18, SL24**

**ATW LOCATIONS**



**For 83" HD  
Models SL11, SL14, SL18, SL24,  
SL31, SL44, SL48, SL84**

**ATW LOCATIONS**



# Concealed Geared Hinges




- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- NOTE: For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.


## For 83" LL Models SL11, SL14, SL18, SL24, SL84

### ATW LOCATIONS



## For 85" SD Models SL11, SL14, SL18, SL24

### ATW LOCATIONS




- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- **NOTE:** For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.


**For 85" HD  
Models SL11, SL14, SL18,  
SL24, SL84**

**ATW LOCATIONS**



**For 85" LL  
Models SL11, SL14,  
SL18, SL24, SL84**

**ATW LOCATIONS**



# Concealed Geared Hinges




- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- NOTE: For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.


**For 95" SD  
Models SL11, SL14,  
SL18, SL24**

**ATW LOCATIONS**



**For 95" HD  
Models SL11, SL14, SL18, SL24,  
SL31, SL44, SL48, SL84**

**ATW LOCATIONS**




- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- **NOTE:** For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.


**For 95" LL  
Models SL11, SL14,  
SL18, SL24, SL84**

**ATW LOCATIONS**



**For 120" HD  
Models SL11, SL14, SL18,  
SL24, SL84**

**ATW LOCATIONS**



# Concealed Geared Hinges



- All dimensions are measured in inches from the top of the door to the centerline of the ATW panels.
- Choose location for ATW prep. ATW4 = 1 location; ATW8 = 1 location; ATW12 = 1 location.

- Please contact the factory for ATW location templates for SL12, SL26, and SL27 hinges.
- **NOTE:** For 90-degree openings, please specify at time of order for no upcharge. There will be an upcharge for 90-degree ATW cover plates when ordered separately and clear or bronze must be specified.

**For 120 LL  
Models SL11, SL14,  
SL18, SL24, SL84**

**ATW LOCATIONS**

