

## SL57 95" SD

All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes and bearings.

Dimensions shown inside boxes are frame facing mounting screw holes.

Choose location for CTW prep from bearing slots dimensioned. CTW4 = 1 location; CTW5 = 1 location.

## SL57 Profile



